

Fitting instructions

1. Prepare circular hole in floor 60mm minimum, 100mm maximum, 75mm deep.
2. Drill six holes in the floor and tap in wall plugs.
3. Push the decorative cover (1) onto the lower portion of the upright tube (2).
4. Pass the feed pipes (5) through the hole in the floor and screw the mounting flange (4) to the wall plugs in the floor.
5. Push the decorative cover (1) onto the floor.
6. Insert the 1mm or 1.5mm O-ring (6) (choose the suitable one for your product) in the spare part pack between the spout and the upright tube(2).
7. Screw the collar (7) of the spout onto the upright tube(2), hand tighten only.
8. Fit the hose(9) to the outlet, and the handset (11) to the hose, ensuring sealing washers (10) are in place.
9. Connect the feed pipes to supply and check thoroughly for leaks.

15mm
COMPRESSION

