

PRODUCT CARE GUIDE

TO MAINTAIN THE APPEARANCE OF THIS PRODUCT, WE RECOMMEND IT SHOULD BE CLEANED USING A SOFT CLOTH AND A NON-ABRASIVE CLEANING PRODUCT. A SIMPLE SOLUTION OF WARM WATER AND A MILD LIQUID NON-ANTIBACTERIAL DETERGENT GENERALLY DOES AN EXCELLENT JOB. ENSURE THAT THE PRODUCT IS RINSED THOROUGHLY AND WIPED DRY.

NOTE

NEVER USE ANY FORM OF ABRASIVE CLEANER OR APPLICATOR AS THEY OFTEN CONTAIN SAND OR SILICA AND WILL EVENTUALLY SCRATCH THE SURFACE. ANY OTHER CLEANING ACTION WILL INVALIDATE YOUR WARRANTY.

CARE

THE GLOSS SURFACE OF THE SINK IS SUSCEPTIBLE TO DAMAGE FROM SHARP AND METALLIC OBJECTS. THE WORST OFFENDER IS METAL CUTLERY. TRY TO AVOID METAL OBJECTS COMING INTO CONTACT WITH THE SURFACE BY USING PROTECTIVE PLASTIC BOWLS, WIRE GRID CUTLERY HOLDERS AND DRAINERS WITH NON-ABRASIVE BASES.

PLEASE DO NOT OVER TIGHTEN ANY FITTINGS AS THIS MAY CAUSE THE SURFACE OF YOUR CERAMIC SINK TO CRACK.

OUR SINKS FEATURE



ODOUR
RESISTANT



HEAT
RESISTANT



IMPACT
RESISTANT



CHEMICAL
RESISTANT



DIRT & STAIN
RESISTANT



NATURAL
MATERIAL



10 YEAR
GUARANTEE



WASTE
DISPOSAL
COMPATIBLE



RECYCLABLE